



BBPGlobal
Add voice to your internet

Netcomm V85 VoIP Phone Configuration Instructions

Version 1.0

A. Physical Connection

1. Connect the device as illustrated



B. VoIP Settings



1. Connect your PC to V85 on PC Port
2. In the typical environment the ADSL modem or broadband router will assign an IP address to the V85. To locate the IP address:
Press "MENU/OK" → "View" → "Network Vaule" → IP Address
3. Login the V85 via any web browser e.g. Internet Explorer by typing in the IP address. By default, type **admin** for both username and password.
4. Click on the left-hand menu item in the Overview screen, called "SIP"
5. Input the information as illustrated

SIP

NetComm®

- Overview
- Network
- SIP**
- Phone
- System

■ Sip Parameters:

1. Phone Number:
2. Password:
3. Auth ID:
4. SIP Domain Name:
5. Local Port:
6. Proxy On:
7. Proxy Addr:
8. Proxy Port:
9. OutbndProxy:
10. OutbndProxyIP:
11. OutbndProxyPrt:
12. STUN Server:
13. STUN Address:
14. STUN Server Port:
15. Port Forwarding Support:
16. NAT WAN IP Addr:

Set

■ Forward Mode:

1. Immediate:
2. Immed Number:
3. Busy:
4. Busy Number:
5. No Answer:
6. NoAns Number:
7. NoAns Time:

Set

■ Advanced:

1. Reg Expire:
2. RTP Port:
3. Codec: G711u G711a G729 G723
4. RTP Packet Interval: 20ms 40ms

Set

6. Click "Set" button to confirm the settings
7. Click on the left-hand menu item in the Overview screen, called "System"
8. Click "Reboot", then "OK" to apply all the settings

The whole reboot procedure takes about one minute. DO NOT turn off power during the reboot procedure.